
Sennen

Outdoor post and path light

MODEL: HA144223-01B

DESIGN DRAWING



⚠ **Read all instructions before you start, and keep them for future reference.**

Installation precautions

1. Turn off the power at the breaker before you start, and check the wires are dead with a voltage tester.
2. If you are not sure how to wire it, have a licensed electrician do it. Follow local electrical codes.
3. Fix the light only to a solid, level base.
4. For outdoor use, keep every connection inside a weatherproof box.


Tools needed


Phillips screwdriver


Wire stripper


Voltage tester



Step ladder


Drill


Parts list

CHECK ALL PARTS BEFORE YOU START

A ×1


Outdoor light

B ×1 set



Mounting screws and anchors

Wiring

	Wire	House supply	Fixture
L	Live (hot)	black	black or marked wire
N	Neutral	white	white or ribbed wire
G	Ground	green or bare copper	green or green-yellow

Join each pair with wire connectors. Connect ground to the green screw on the bracket or plate if there is one.

Exploded view




A Outdoor light ×1

B Mounting screws and anchors ×1 set

Installation


STEPS 1–4 OF 4

1




Mark the fixing holes on a solid, level base. Drill them and fit the anchors (B).

2




Connect the wires in a weatherproof box: L to L, N to N, G to G.

3



Fix the light (A) to its base with the screws.

4



Turn the breaker on and switch on.

Care

- Wipe clean with a soft, dry cloth.
- Always switch off the power and let the fixture cool before cleaning.
- Dry the steel right away after washing and keep grass clippings off the lens.

Troubleshooting

Problem	What to do
Light does not come on	Check the breaker and wall switch. Turn the power off and check each wire connection is tight.
Light flickers	Turn the power off and re-make the connections. On a dimmable model, use an LED-rated dimmer.
Fixture is not level	Loosen the mounting screws, level the base and retighten.

Need help?
Email info@norafurnish.com with your order number and a photo. A part missing or damaged? We will send a new one.

NoraFurnish