


Sylvan

Rechargeable lamp

MODEL: LI002650-0

DESIGN DRAWING



Shown: 3.3"x3.3"x3.5"



Read all instructions before you start, and keep them for future reference.

**Installation precautions**


1. Charge with a standard USB adapter, away from water and heat.
2. Do not open the housing: the battery is built in.

Tools needed

USB charger

Parts list

CHECK ALL PARTS BEFORE YOU START


A**×1**

Rechargeable lamp

Power

Built-in rechargeable battery, charged over USB.

Exploded view




A Rechargeable lamp ×1

Size	Width	Diameter	Depth	Height
3.3"x3.3"x3.5"	3.3"	—	3.3"	3.5"
3.3"x3.3"x4.6"	3.3"	—	3.3"	4.6"
2.3"x2.3"x3.9"	2.3"	—	2.3"	3.9"
6.7"x2.4"x4.5"	6.7"	—	2.4"	4.5"
2.3"x3.1"	—	2.3"	—	3.1"
3.3"x3.5"	—	3.3"	—	3.5"
3.3"x4.6"	—	3.3"	—	4.6"
2.3"x3"	—	2.3"	—	3"

Installation


STEPS 1-3 OF 3

1




Charge the lamp (A) fully before first use.

2



Touch the top to switch on and change the brightness.

3



Recharge it when the light dims.

Care

- Wipe clean with a soft, dry cloth.
- Keep it away from moisture and direct sunlight, which is what dries and fades wood.
- Do not use solvent cleaners on the shade.

Troubleshooting

Problem	What to do
Light does not come on	Charge it fully over USB and check the switch is on.
Light is dim or goes off early	Recharge it fully. Run time drops as the battery runs down.

Need help?

Email info@norafurnish.com with your order number and a photo. A part missing or damaged? We will send a new one.

NoraFurnish