

# Gemini

Wall light

MODEL: NF-BK-10046594777402

## DESIGN DRAWING



Read all instructions before you start, and keep them for future reference.



### Installation precautions

1. Turn off the power at the breaker before you start, and check the wires are dead with a voltage tester.
2. If you are not sure how to wire it, have a licensed electrician do it. Follow local electrical codes.
3. Make sure the ceiling or wall box can carry the weight of the fixture.
4. Wear gloves so the finish stays clean.

### Tools needed



Phillips screwdriver



Wire stripper



Voltage tester



Step ladder

### Parts list

CHECK ALL PARTS BEFORE YOU START

**A****×1**

Wall light

**B****×1 set**


Mounting plate and screws

### Wiring

|          | Wire       | House supply         | Fixture               |
|----------|------------|----------------------|-----------------------|
| <b>L</b> | Live (hot) | black                | black or marked wire  |
| <b>N</b> | Neutral    | white                | white or ribbed wire  |
| <b>G</b> | Ground     | green or bare copper | green or green-yellow |

Join each pair with wire connectors. Connect ground to the green screw on the bracket or plate if there is one.

Exploded view




**A** Wall light ×1

**B** Mounting plate and screws ×1 set

## Installation

STEPS 1-5 OF 5

1




Fix the mounting plate (B) to the wall box with its screws.

2


### House supply

- L** Live (hot)  
black
- N** Neutral  
white
- G** Ground  
green or bare




Connect the wires: L to L, N to N, G to G, with wire connectors.

3





Fit the light (A) onto the plate and secure it.

4



Fit the bulb.

5



Turn the breaker on and switch on.

## Care

- Wipe clean with a soft, dry cloth.
- Switch the power off and let the fixture cool before cleaning.
- Avoid acidic and abrasive cleaners, which can etch natural stone.

## Troubleshooting

| Problem                | What to do                                                                                     |
|------------------------|------------------------------------------------------------------------------------------------|
| Light does not come on | Check the breaker and wall switch. Turn the power off and check each wire connection is tight. |
| Light flickers         | Turn the power off and re-make the connections. On a dimmable model, use an LED-rated dimmer.  |
| Fixture sits crooked   | Loosen the mounting screws, level the bracket and retighten.                                   |

### Need help?

Email [info@norafurnish.com](mailto:info@norafurnish.com) with your order number and a photo. A part missing or damaged? We will send a new one.

*NoraFurnish*