
Abbey Chamberstick

Candle holder

MODEL: NF-B33-007

DESIGN DRAWING



⚠ Read all instructions before you start, and keep them for future reference.

Handling precautions

1. Never leave a burning candle unattended.
2. Keep burning candles away from curtains, children and pets.
3. Burn on a level, heat-resistant surface, away from drafts.
4. Let the holder cool completely before you touch, move or clean it.

Tools needed



No tools needed



Soft cloth




Taper candles (not included)

Parts list

CHECK ALL PARTS BEFORE YOU START

A ×1




Abbey Chamberstick

Care & Setup


STEPS 1–5 OF 5

1




Unpack everything and remove all the packing material.

2




Fit a taper candle that sits firmly in the holder. Candles are not included.

3




Set it on a level, heat-resistant surface, away from drafts and clear of curtains or anything above it.

4



Never leave a burning candle unattended.

5



Let the holder cool completely before handling or cleaning.

Care

- Let the holder cool completely before handling or cleaning.
- Wipe clean with a soft, dry cloth.
- Do not put in the dishwasher.
- Never leave a burning candle unattended.

Need help?
Email info@norafurnish.com with your order number and a photo. A part missing or damaged? We will send a new one.

NoraFurnish