Ridge

Solar wall light

MODEL: HA078060-0

DESIGN DRAWING



2.8 inches tall, 2.8 inches wide and 1.6 inches deep; About 0.6 or 0.7 lb each

⚠ **Read all instructions before you start, and keep them for future reference.**

Installation precautions

1. Place the panel where it gets several hours of direct sun.
2. Do not open the sealed panel or battery compartment.
3. Keep the panel clear of leaves and snow.

Tools needed



Pencil | Level | Drill | Phillips screwdriver

Parts list


CHECK ALL PARTS BEFORE YOU START

A ×1



Solar wall light

B ×1 set




Mounting hardware

Power

Solar powered: the built-in panel charges the battery by day.

Exploded view




A Solar wall light ×1

B Mounting hardware ×1 set

Installation


STEPS 1–5 OF 5

1




Switch the light (A) on.

2




Pick a spot with several hours of direct sun. Level it and mark the holes.

3




Drill the holes and push in the wall anchors (B).

4



Fix the light (A) to the wall.

5



It charges by day and comes on by itself at dusk.

Care

- Wipe clean with a soft, dry cloth.
- Wipe the solar panel regularly so dust and leaves do not stop it from charging well.
- Avoid abrasive cleaners on the clear shade.

Troubleshooting

Problem	What to do
Lights do not come on	Check the panel is switched on and gets several hours of direct sun. Charge a full day.
Short run time	Clean the panel and move it out of shade. Run time drops on cloudy days.

Need help?
Email info@norafurnish.com with your order number and a photo. A part missing or damaged? We will send a new one.

NoraFurnish