


Cadran

LED Wall Art

MODEL: LI003020

DESIGN DRAWING



Shown: Single Sided



Read all instructions before you start, and keep them for future reference.

**Mounting precautions**

1. Check what is behind the wall before drilling: pipes, wires and studs.
2. Use anchors suited to your wall and to the weight of the piece.
3. Unplug before cleaning. Keep the cord out of walkways.

Tools needed

Pencil



Level




Drill




Phillips screwdriver

Parts list

CHECK ALL PARTS BEFORE YOU START

A**×1**

Cadran

B**×1 set**

Mounting hardware


Power

Built-in rechargeable battery, charged over USB.

Mounting


STEPS 1-5 OF 5

1




Hold the piece (A) in place, level it and mark the hanging points.

2




Drill the holes and push in wall anchors (B).

3




Drive the screws in, leaving the heads out slightly to hang on.

4



Hang the piece (A) on the screws.

5



Run the cord to the outlet, plug in and switch on.

Care

- Wipe clean with a soft, dry cloth.
- Clean glass or acrylic with a soft damp cloth and dry it straight away.
- Do not use abrasive cleaners.

Troubleshooting

Problem	What to do
Piece is not level	Loosen one screw slightly or add a small felt pad behind the low side.
Screw will not hold	Use a larger wall anchor, or fix into a stud.

Need help?

Email info@norafurnish.com with your order number and a photo. A part missing or damaged? We will send a new one.

NoraFurnish