
Larme

Outdoor floor light, hardwired, solar or battery

MODEL: HA083628

DESIGN DRAWING



9.4 inches across and 31.5 inches tall, 15 inches across and 48 inches tall, or 18.9 inches across and 59.8 inches tall; About 4.4 to 11 lb depending on size and power choice

⚠ **Read all instructions before you start, and keep them for future reference.**

Installation precautions

1. Turn off the power at the breaker before any wiring, and have a licensed electrician make the connection.
2. Keep every connection inside a weatherproof box.
3. Stand it on a firm, level surface where it cannot tip.
4. Place the panel where it gets several hours of direct sun.

Tools needed


Phillips screwdriver


Wire stripper



Voltage tester


No tools needed

Parts list

CHECK ALL PARTS BEFORE YOU START

A ×1



Outdoor light

Wiring

	Wire	House supply	Fixture
L	Live (hot)	black	black or marked wire
N	Neutral	white	white or ribbed wire
G	Ground	green or bare copper	green or green-yellow

Hardwired: Join each pair with wire connectors. Connect ground to the green screw on the bracket or plate if there is one. Solar: no wiring. The built-in panel charges the battery by day.

Exploded view




A Outdoor light ×1

Installation

STEPS 1–6 OF 7

1




Hardwired: Stand it on a firm, level surface near the outdoor power supply.

2


House supply

- **L** Live (hot) black
- **N** Neutral white
- **G** Ground green or bare




Hardwired: Have an electrician connect it in a weatherproof box with the power off: L to L, N to N, G to G.

3




Hardwired: Turn the power on and switch on.

4



Solar: Switch the lamp on.

5



Solar: Let it charge in direct sun for the first full day.

6




Solar: Place it where you want the light. It comes on by itself at dusk.

Installation

STEP 7 OF 7

7



Battery version: charge it fully before first use, then switch on with the button.

Care

- Wipe clean with a soft, dry cloth.
- A damp cloth removes garden dust and water marks; dry it afterward.
- Do not use solvents or abrasive cleaners on the surface.

Troubleshooting

Problem	What to do
Light does not come on	Check the breaker and wall switch. Turn the power off and check each wire connection is tight.
Light flickers	Turn the power off and re-make the connections. On a dimmable model, use an LED-rated dimmer.
Lights do not come on	Check the panel is switched on and gets several hours of direct sun. Charge a full day.
Short run time	Clean the panel and move it out of shade. Run time drops on cloudy days.

Need help?
Email info@norafurnish.com with your order number and a photo. A part missing or damaged? We will send a new one.

NoraFurnish